

# Guest Vibrating Paging



Customer Satisfaction  
**GUARANTEED**  
 or your money back!

## Vibrating Coaster Guest Paging

Are long waits typical for your restaurant guests? Is your restaurant located in a shopping center or another environment where your guests can wander and shop until they are paged? If so, it's important to be prepared with a guest paging system that will alert a guest when their table is ready. Coaster paging is used in a number of different restaurant environments that require individual paging for their guests.

The operation of the coaster paging system is simple: When your restaurant is on a wait, hand your guests a coaster as you add their name to your wait list, and explain that it will alert them when their table is available. When the guest's table is ready, key the coaster number into the transmitter and press "SEND." For example, to page coaster number 11, press "1-1-SEND" and the coaster will signal the guest.

## MultiPage UHF Transmitter \$399

The MultiPage Transmitter is a reliable, 460MHz long-range paging system with a 1/4- to 1/2-mile range. This on-premise paging systems has no monthly service fee. The transmitter operates in the 460 MHz UHF band and is successful in all restaurants, including multi-building/multi-level facilities. The MultiPage has a 3-year warranty and a 30-day money-back guarantee. Neither false pages nor system interference is a risk with this system.

## Vibrating Coasters \$64 each

The Vibrating Coaster is sturdy, reliable, and easy to use. Designed specifically for the restaurant industry, these coasters have nickel-metal rechargeable batteries. To charge the coasters, simply stack them on a coaster charging base (1-15 coasters per base) and plug into an AC wall outlet. The coasters charge until individually removed from the stack. Charging resumes when the coaster is returned to the charging stack. When ordering coasters, there is no minimum quantity purchase requirement and add-ons can be purchased at any time.

## Out-of-Range Feature

When this user-programmable option is activated, the coaster will play a melody to inform the guest that they are out of range and can miss their page from the host. This melody will only stop if the guest steps back into the paging range. This feature also reminds the guest to return the coaster to the host stand in case the host forgets. Default programming from the factory is Out of Range OFF.

## Auto Locate Feature

The auto locate feature causes ALL coasters (that are not on the charging stack) to signal at once. An ideal time to use this feature is at the end of each shift as a check-out procedure for the hostess. This ensures that all pagers are returned to the charger, even if a guest left their coaster on a chair in the waiting area.

## Alert Mode Options

The Vibrating Coaster Paging System features user-programmable alert modes. With this feature you have the option of changing the way your coaster alerts the guests. The available choices include "VIBRATE ONLY," "FLASH and VIBRATE," and "FLASH and BEEP."



**Custom Labels**  
 We now offer custom labels for our coasters. Please call for pricing details.

## System Accessories

Charger Base*	\$79
Charger Power Supply**	\$20
Charger Jumper Wire	\$4

\* One charger base holds up to 15 coasters  
 \*\* Up to 4 charger bases are connected by jumper wires on 1 power supply

**microframe**®