

Installing Buttons

Step 1: Loosen screws in green terminal block.

Step 2: Insert the wire used for the "UP" button in the side of the terminal block and tighten the screw.

Step 3: Insert the wire used for the "DOWN" button in the side of the terminal block and tighten the screw.

Step 4: Insert the wire used for the "COMMON" in the side of the terminal block and tighten the screw. (This wire will be used on one side of each button.)

Step 5: Connect the wire used for the "UP" button to one side of the first button.

Step 6: Connect the wire used for the "DOWN" button to one side of the second button.

Step 7: Connect the wire used for the "COMMON" terminal to both push buttons.

