

DataTrack One-Touch Paging

FEATURES

DATA TRACK WITH CANCEL PANEL

- Ultra-reliable 460 MHz transmitting frequency
- Simple “one-touch” paging
- 14-way call system
- Cancel Panel to verify a page has been answered

POCKET PAGER

- Vibrate/tone or vibrate only alert options
- Supplied with belt clip and holster
- Uses one AAA alkaline battery (included)
- Low battery indicator



DATATRACK WITH CANCEL PANEL

The DataTrack One-Touch Paging System is designed to page wait staff with the simple press of a button.

The system features individual call buttons that can transmit to any of 14 on-site pagers. The datatrack surface works with dry erase markers to keep track of who’s carrying which pager.

When paging, simply press the call button for the person you wish to page. A red light will appear in the corner of the button pressed to confirm a page was sent.

The Cancel Panel ensures every page is answered efficiently. After the initial page has been sent, the system allows two minutes and 40 seconds for the person carrying the pager to acknowledge the page by pressing the corresponding call button on the Cancel Panel.

If a page has not been acknowledged/canceled within the allotted time the transmitter automatically sends a page to a “manager” pager to alert management of the slow response time. (Note: the DataTrack can be ordered without the Cancel Panel.) The manager’s pager is only available with the Cancel Panel.

The DataTrack makes paging easy, even in fast-paced, loud, and crowded environments.

POCKET PAGER

The Pocket Pager is compact and easy to use. Available in vibrate only or vibrate/tone mode, the Pocket Pager is programmed for one button operation. The Pocket Pager receives a page from the transmitter, then vibrates or sounds a tone (depending on programming), then displays a text or numeric message if one was sent.

The Pocket Pager offers unlimited numeric messages, and three 12-character, pre-programmed text messages. A low-battery symbol indicates when the battery level is low.

The Pocket Pager is one of the most versatile pagers on the market. Microframe can assist you with your programming decisions and set up the pagers according to your specifications.

PRICING

B3063 DataTrack with Cancel Panel.....	\$839
B3061 DataTrack without Cancel Panel.....	\$529
B3017 Pocket Pager.....	\$39
B3065 Wall-Mounting Brackets.....	\$14
(Each transmitter requires one bracket for wall mounting)	

