



DATAPAGE LITE+COASTER SPECS

On-Premise Paging

Features

The Coaster Out of Range feature informs customers that they are out of range the moment they step out by continuously playing a melody until the moment they step back in. This feature helps reduce the number of missed pages as well as accidental coaster walk-outs. Coasters are rechargeable and will last approximately 3-5 years before replacement of the battery is necessary.

Operation

The transmitter and charging base simply plug into an outlet using the power adapters supplied. Additional charging bases and coasters may be purchased at any time. Coasters stack on top of the charging base in groups of 15 and are always charging until removed from the stack. To page a guest, simply enter the assigned coaster number into the transmitter.



DataPage Lite Transmitter w/Coaster



DataPage II Transmitter



DataPage Lite w/Coasters Specifications

Frequency Range	457.575 MHz
Baud Rate	1200
Distance Range	1/4 to 1/2 Mile
FCC Approval No	JRNUSASERILINK
Transmitter Mounting	Desk Mounted
Coaster Charging	Stacks of 15 on Desk Top

Support and Sales
800-635-3811

Microframe® Corporation
www.microframecorp.com

P.O. Box 1700
Broken Arrow, OK 74013