

guest *vibrating* paging

by microframe corporation

1-800-635-3811

restaurantpager.com



DataPage Lite with Coaster Paging

Are long waits typical for your restaurant guests? If so, it's important to be prepared with a guest paging system that will eliminate confusion, steer the masses away from the host stand, and increase table turns.

Coaster pagers are a popular method of paging guests. The operation of the coaster paging system is simple.

Any time your restaurant is on a wait, as you add the guest's name to your wait list, hand them a coaster and explain that it will signal when their table is available. Be sure to write the coaster number on the wait list as well to avoid loss or theft. When the guest's table is ready, key the coaster number into the transmitter and press "SEND." For example, to page coaster number 11, press "1-1-SEND" and the coaster will signal the guest.

As the guests arrive to the host stand after being paged, the host staff will greet the guests, retrieve the coaster and show each party to their appropriate seat. Coaster paging is widely used across the country in a number of different restaurants that enjoy the benefits of a silent paging system.

DataPage Lite UHF Transmitter \$399

The DataPage Lite is a rugged, long-range, "on-premise" paging system built for commercial use that features unlimited paging with no monthly service fee. This powerful transmitter operates in the 460 MHz UHF band and transmits 2 miles in outdoor field testing. In actual use, the range is 1/4 to 1/2 mile, depending on building structure and surroundings.

The DataPage Lite carries a 2-year warranty and a 30-day money-back guarantee. Over 2,000,000 transmitter codes and different baud rates eliminate false pages and system interference.



Restaurant Coasters \$64 each

The Restaurant Coaster is sturdy, reliable, and easy to use. Designed specifically for the restaurant industry, these coasters have nickel-metal rechargeable batteries. To charge the coasters simply stack them on a Microframe charging base (1-15 coasters per base) and plug into an AC wall outlet. The coasters charge until individually removed from the stack. Charging resumes when the coaster is returned to the charging stack. When ordering coasters, there is no minimum quantity purchase requirement and add-ons can be purchased at any time.



Out-of-Range Feature

When this user-programmable option is activated, the coaster will play a melody to inform the guest that they are out of range and will miss their page. This melody will only stop if the guest steps back into the paging range. This feature also reminds the guest to return the coaster should the host forget to get it back. Default from the factory is Out of Range OFF.

Auto Locate Feature

The auto locate feature causes ALL coasters (that are not on the charging stack) to signal at once. An ideal time to use this feature is at the end of each shift as a check-out procedure for the hostess. This guarantees that all pagers are returned to the charger, even if a guest left their coaster on a chair in the waiting area.

Alert Mode Options

The DataPage Lite Coaster Paging System features user-programmable alert modes. With this feature you have the option of changing the way your coaster alerts the guests. The available choices include "VIBRATE ONLY," "FLASH and VIBRATE," and "FLASH and BEEP."



Customizable Labels

We now offer custom labels for our coasters. Please call for pricing details.

System Accessories

- Charger Base*.....\$79
- Charger Power Supply**.....\$20
- Charger Jumper Wire.....\$4

- One charger base holds up to 15 coasters
- ** Up to 4 charger bases are connected by jumper wires on 1 power supply



P.O. Box 1700 • Broken Arrow, OK 74013 • 800.635.3811 • www.restaurantpager.com