

TV Interface

INTERFACE SPECIFICATIONS

- The height of the characters is .052 x screen size.
- Select which corner the numbers will appear with remote doorbell button.
- The system works with Video In and Video Out.
- Power comes from the 900 series keypad.
- May have up to 32 keypads.
- Enter or delete numbers from any keypad.
- May use with or without LED displays.
- Accepts standard RS-170A NTSC Video Signals.

TV VIDEO PAGER INTERFACE

Page any person by simply typing their number into the keypad. The number will appear both on the TV and the Large Remote Display, if connected.



OPERATION

Numbers entered into the keypad appear in the corner of the television, as well as on any 900 Series display wired to the system. You don't have to worry about the numbers covering a sports score or closed captioning text because a button wired to the Model 190 Interface allows the operator to toggle the numbers between each of the four corners of the TV screen.

MULTIPLE TELEVISIONS

The Model 190 TV Interface operates on the TV video signal like the video out of the VCR or satellite receiver. You may connect as many televisions as you wish viewing the same program (hockey, football, skating) with a single Model 190 Television Interface. However, if you are showing different programs at the same time on different TV's, you will need a separate Model 190 for each different program. The Model 190 only operates on video signals; therefore it will not affect any channels (2-99) tuned in using the channel selector.

INTERFACE CONNECTION

The Model 190 accepts standard RS-170A NTSC signals (the video "out" connection on a VCR) and mixes the numbers with the video. Simply connect the video out of a receiver into the Model 190. Then connect the video out of the Model 190 (which contains numbers and video) to the video input on the TV(s).

Note: The Model 190 Television Interface is compatible with the Series 900 paging system. Combine television paging and LED Visual-Paging for enhanced viewing.



The Model 190 Television Interface is ideal for television paging in the waiting area of a restaurant or paging via a large screen in a church sanctuary or auditorium.

PRICING

Model 190.....	\$349
(price includes 20 ft of wire and one push button)	
Model 904 Keypad (2-, 3-, & 4-digit paging).....	\$249
Model 906 Keypad (for 6-digit paging).....	\$349
920 Display.....	\$199
930 Display.....	\$229
940 Display.....	\$269
960 Display.....	\$349

