

6200 Series Timer

APPLICATIONS

- The 6200 Timer system serves as a lecturer or event timer helping to coordinate timed and scheduled events, such as stage performances, audio and visual recording, radio and television broadcasts.

FEATURES

- Count up or count down with two timers in one
- Operates in either count up or count down mode
- View both timers simultaneously on the timer keypad
- Program timer keypad to automatically reset, reload and restart



TIMER KEYPAD

The Keypad's LCD display shows both "A" and "B" timers simultaneously and allows the user to select which timer will appear on the remote display. Changes entered on timer "A" do not affect the contents and/or mode of timer "B." Either timer can count up or down and start or stop independently. Timer "A" can start timer "B" or show the time of day.

The Keypad features a time-of-day clock button to display a clock when not using the timer function. The Timer Keypad's LCD screen provides optimum control by the operator by viewing the timer as it is being displayed on the LCD display that may be wired to the front of the room, another location or near the speaker.

6200 Keypad



DISPLAY OPTIONS

Series 6200 Timers are available in 4 and 6-digit versions. The 4-digit display shows hours/minutes or minutes/seconds, and the 6-digit display shows hours/minutes/seconds. These displays feature 5.5" tall characters visible up to 125 feet. They feature attractive extruded aluminum cases, anodized for scratch-resistant purposes with red LEDs. Included with the system is everything needed for complete installation. One cable from the timer supplies both power and signal to the display(s). Multiple displays can be added to enhance viewing.

62104 Timer System



MINI-DISPLAY

The Microframe Model 941 Mini-Display features 1-inch tall digits viewable from up to 30 feet and shows 4-digit numbers. The Model 941 is operated by the 6200 Timer Keypad or the Model 904 Keypad.

**Model 941
Mini-Display**

PRICING

62104 Timer System	\$638
One Model 6200 Keypad & Power Adapter	
One Model 940 4-digit Display	
100-ft (30m) Connecting Cable	
Extra Model 940 Display.....	\$269
Model 941 Mini-Display	\$199

62106 Timer System	\$718
One Model 6200 Keypad & Power Adapter	
One Model 960 6-digit Display	
100-ft (30m) Connecting Cable	
Extra Model 960 Display.....	\$349
6200 Timer Keypad	\$349

**Each Timer System includes one Display, one Model 6200 Keypad and Power Adapter, and 100 feet of connecting cable for screwdown connectors.



6300 Series Timer/Counter/Clock

SERIES 6300 TIMER/COUNTER/CLOCK

The 6300 Series display is the most versatile display that Microframe has to offer. Whether you need a special event timer, a countdown clock for a sporting event, a wall clock for your business, an industrial unit counter for manufacturing, New Year's countdown clock, or a production takt timer; Microframe's 6300 Series timer/clock/counter is the high-quality, low-cost solution to meet your needs. The display has large 5.5" tall numbers that are visible up to 125 feet featuring a black extruded aluminum case with red LEDs.



Model 6360 Display



Remote Control

REMOTE CONTROL

The wireless remote control allows you to advance the numbers, go back a number, reset the numbers, and set up the programming. Multiple remotes can be used on one or more displays. The remote has a range of between 15 to 30 feet (line of sight).

COUNTDOWN TIMER

The count up or countdown timers will count days, hours, minutes, seconds, and 100th of seconds. The timer can be set to any time and begin counting up or down with the press of a button on the remote or with the push button wired to the back of the display.



Model 6340 Display

CLOCK

As technology continually improves, so does Microframe's clock display. With improved internal clock components the result is a very accurate time-of-day clock, available in 4 or 6-digit modes. The 4-digit displays hours and minutes or minutes and seconds. The 6-digit displays hours, minutes, and seconds.

COUNTER

Counter mode is commonly used for manufacturing and production piece counting. The display works with most industrial sensors that are used to communicate the number of units/products produced on a production line. This helps improve the efficiency of your plant and resources by providing immediate visual confirmation of manufacturing outputs.



Model 6330 Display

PRICING

6320 Display System.....	\$248	6340 Display System.....	\$348
One Model 6320 Display		One Model 6340 Display	
One Wireless Remote Control		One Wireless Remote Control	
Extra Display.....	\$229	Extra Display.....	\$329
6330 Display System.....	\$298	6360 Display System.....	\$418
One Model 6330 Display		One Model 6360 Display	
One Wireless Remote Control		One Wireless Remote Control	
Extra Display.....	\$279	Extra Display.....	\$399

