

Vibrating Paging

DATA TRACK WITH CANCEL PANEL

The DataTrack One-Touch Paging System is designed to page with the simple press of a button. The system features individual call buttons that can transmit to any of 14 on-site pagers. When paging the server, simply press the call button for the server you wish to page. A red light will appear in the corner of the button pressed to confirm a page was sent. The Cancel Panel ensures every page is answered efficiently. After the initial page has been sent, the system allows 2 minutes and 40 seconds for the person carrying the pager (i.e. the server, expediter, or food-runner) to acknowledge the page by pressing the corresponding call button on the Cancel Panel. If a page has not been acknowledged/canceled within the allotted time, the transmitter automatically sends a page to a "manager" pager to alert management of the slow response time. *(Note: the DataTrack can be ordered without the Cancel Panel. The manager's pager is only available with the Cancel Panel).* The DataTrack makes calling a server to the kitchen or bar easy, even in fast-paced environments! Food is served hot and drinks are served cold every time resulting in satisfied customers.



DataTrack

The DataTrack System can be ordered for desktop or wall mounting and is powered by a plug-in AC adapter. The Cancel Panel is connected to the master transmitter with a 10' RJ11 cord.

Multiple "master" transmitter units can be located anywhere in the building or complex of buildings, allowing data to be sent from any desired location. For instance, a transmitter could be placed in the kitchen, at the bar and at the host stand, with the Cancel Panel located at the pickup window.



MultiPage

MULTIPAGE UHF TRANSMITTER

The MultiPage is a rugged, long-range, paging system that features unlimited paging (9,999 pager capacity). This powerful transmitter operates in the 460 MHz UHF band and transmits 2 miles in outdoor field testing. In a multi building environment, the range is 1/4 to 1/2 mile depending on building structure and surroundings. The MultiPage offers: unlimited numeric paging and text messages. Text messages such as "See Manager" can be programmed at time of order.

POCKET PAGER

For use with either the DataTrack or MultiPage transmitters, the Pocket Pager is compact and easy to use. Programmed for you at Microframe before shipping, the pagers are available in vibrate only or vibrate/tone mode. The pager can be programmed to display pre-defined "canned" text messages. The messages are limited to 12-characters, including spaces. These pre-defined messages are selected by the user at the time of purchase and factory programmed before shipment.



Pocket Pager

FEATURES AND PRICING

DATATRACK with CANCEL PANEL \$839

- Ultra reliable 460 MHz transmitting frequency
- Simple "one-touch" paging
- 14-way call system
- Cancel Panel to verify a page has been answered

DATATRACK (without Cancel Panel) \$529

WALL-MOUNTING BRACKETS (optional) \$14

- For wall mounting, one bracket is required for each transmitter.

MULTIPAGE TRANSMITTER \$399

- Ultra reliable 460 MHz transmitting frequency
- Up to 9,999 pagers
- Transmit up to 12-digit numeric message codes
- Transmit up to three 12-character text messages
- Available wall mounting bracket

POCKET PAGER \$39

- Vibrate/tone or vibrate only alert options
- LCD display shows pre-defined text messages or numeric messages
- Supplied with belt clip and holster
- Uses one AAA alkaline battery (included)
- Low battery indicator



Visual Paging

BENEFITS

- Maintenance-Free
- Silent Paging
- Multiple Pages Simultaneously
- No Loss or Breakage



SINGLE NUMBER DISPLAYS

The Visual Paging series features your choice of 2-, 3-, or 4-digit displays. These displays feature 5.5" tall characters for visibility up to 125 feet, and can rotate up to 30 numbers at a time. Available in wired or wireless.



MULTI-NUMBER DISPLAYS

Microframe offers multi number displays which feature either four 3-digit numbers or six 2-digit numbers. These 2.5" tall numbers are visible from up to 80 feet. This system

is ideal for paging multiple numbers simultaneously. The wired model can rotate up to 30 numbers at a time and the wireless up to 40 numbers simultaneously.

Hang multiple displays located conveniently across your premises where people are most likely to be. The keypad is rugged enough to survive even industrial conditions and should be located conveniently for the person doing the paging and cancelling.

WIRELESS SYSTEMS

The wireless systems are "plug and play," each display must plug into an AC outlet. The transmitter also plugs into an AC outlet. Paging distance is 1/4 to 1/2 miles indoors.



3430 Multi-Number Wireless System



3530 Wireless System

WIRED SYSTEMS

Wired systems will extend your range to 2,000 feet. The keypad includes a power adapter that plugs into an AC outlet. Multiple displays can be daisy-chained from the keypad, thus eliminating AC power at each display. Additional keypads can be added to allow paging from different locations.



930 Wired System



3620 Multi-Number Wired System

PRICING (WIRED)

Single Number Keypad (904)	\$249
• 2-Digit Display (Model 920)	\$199
• 3-Digit Display (Model 930)	\$229
• 4-Digit Display (Model 940)	\$269
Multi-Number Keypad (9000)	\$349
• Six 2-Digit Display (Model 9620)	\$375
• Four 3-Digit Display (Model 9430).....	\$375

PRICING (WIRELESS)

Single Number Transmitter (3510)	\$399
• 2-Digit Display (Model 3520)	\$299
• 3-Digit Display (Model 3530)	\$349
• 4-Digit Display (Model 3540)	\$399
Multi-Number Transmitter (3610)	\$399
• Six 2-Digit Display (Model 3620)	\$475
• Four 3-Digit Display (Model 3430).....	\$475

