

Model 2000 Vibrating Paging

MODEL 2000 TRANSMITTER

This low-cost system offers unlimited paging with no monthly service fee. The powerful 7-watt transmitter is capable of sending up to 10 message codes to any of 1,000 different pagers. Message codes may be assigned using the numbers 0-9.



Additional transmitters can be added for multiple paging locations. The system operates up to 2 miles in open-field testing under optimum conditions. Testing in warehouse and building environments proved a range up to 1/4 mile. The transmitter can also be table or wall mounted (wall-mounting brackets are included).

PAGER OPTIONS

The Model 2000 gives you three pager choices: Model 200 vibrate only pager, Model 201 vibrate/tone pager, and Model 202 vibrate only with magnetic swipe "off" feature. All pagers offered with this system have a spring-loaded belt clip and a single-digit LED display. The pager remembers the last 8 messages which can be reviewed by pressing a button. For convenience, each pager has a white message tab that reminds the user what the message code is.



Pagers are programmed by the user to respond to any 3-digit number. These numbers can be reassigned by reprogramming the pagers.

FEATURES AND PRICING

B2000 TRANSMITTER.....\$139

- 27 MHz citizens band system
- Pages Up to 1,000 pagers
- Transmit up to 10 different message codes
- Transmitter displays pager number and code
- Group page function
- No FCC license required

B200 VIBRATE ONLY PAGER.....\$55

B202 VIBRATE ONLY WITH MAGNETIC SWIPE....\$59

B201 VIBRATE/TONE PAGER.....\$62

- Battery life 9 months (turn off when not in use)
- Programmable pager number assignment
- Bright LED shows message codes
- Spring-loaded belt clip
- 2 AAA alkaline batteries required
- Low battery indicator

