

# DataPage II

## BENEFITS

- Telephone/Computer Interface
- "On-premise" paging system
- Features unlimited paging
- No monthly service fee
- 460 MHz transmitter's range is 1/4 to 1/2 mile
- Outperforms 27 MHz systems

## DATA PAGE II TRANSMITTER

The DataPage II works with the Scope Pager or the GEO40 Pager. The transmitter sends numeric message codes of up to 12-digits to any of 9,999 different pagers. An optional telephone interface allows any internal phone to be used for paging, while an optional computer interface allows messages to be sent from any network computer.

## GEO40

The Scope GEO 40 Pager is a 2-line (20-character per line) alphanumeric pager with scrolling capabilities. The user can program the pager to vibrate only or tone/vibrate, and the pager offers clear text messaging. Group and individual paging is also available.

## POCKET PAGER

The Scope Pocket Pager is a one line, 12-character pager. Available in vibrate only or vibrate/tone mode, the pager can be pre-programmed to display up to three "canned" text messages.

All pagers can be turned off simultaneously from the transmitter, or individually from the pager. Group and individual paging is also available. In addition, pagers can be pre-programmed to only turn off at the base by disabling the off button, thus eliminating accidental turn off by the user.



DataPage II



GEO40



Pocket Pager

## PRICING

DataPage II . . . . .	\$ 679
Pocket Pager . . . . .	\$ 39
GEO40 Alphanumeric Pager . . . . .	\$ 109

## TELEPHONE INTERFACE

DataPage II with DTMF Telephone Interface. . . . .	\$ 729
DataPage II with LP Telephone Interface . . . . .	\$ 769

## COMPUTER INTERFACE

DataPage II with Serial Port. . . . .	\$ 729
DataPage II with Serial Port & DTMF Interface . . . . .	\$ 769
DataPage II with Serial Port & LP Interface. . . . .	\$ 799
Page Connect Software . . . . .	\$399

## ACCESSORIES

Dipole Antenna. . . . .	\$ 89
Transmitter Mounting Bracket . . . . .	\$ 24

